


Vectrex Animation Multiconn

Users Manual - read carefully before operating!

Welcome to your new Vectrex Animation Multiconn Multicart with 8 games selection. Please select game no. as seen in table below!



Game no.	JP2	JP1	JP0
1	0	0	0
2	0	0	X
3	0	X	0
4	0	X	X
5	X	0	0
6	X	0	X
7	X	X	0
8	X	X	X

When game selected gently insert Animation Multiconn into Vectrex game slot as shown in picture below!



Note that the EPROM will be on top side and the smaller edge of the Animation Multiconn is being inserted into slot.

Don't ever try to insert the Animation Multiconn wrong way - you'll damage the Multiconn AND your Vectrex

When you need to replace the EPROM by yourself putting a small knife (ie. Swiss army knife) between EPROM and socket might be helpful.

happy gaming!